



2921 McBride Ct. Hamilton, OH 45011 Ph:(800) 847-3736 www.Vinylmax.com Orders@Vinylmax.com

Inspire 4100 Series Single Hung Window OPERATING INSTRUCTIONS for Factory-Installed Window Opening Control Devices (WOCDs)

ASTM F2090-21

- 1) Unlock the window (Fig. 1).
- 2) Depress EACH ORANGE DOT TONGUE (Fig. 2) on the WOCDs to lock in recessed position, then raise past the WOCDs.
- 3) The WOCDs will automatically reset when the sash is closed; raise sash to confirm it has reset. (Fig. 3).







Figure 1

Figure 2

Figure 3

- If the WOCDs do not automatically reset, close & lock the window & call (800) 847-3736 to speak with Customer Service.
- Test each WOCD's operation at least once a month for proper operation & ensure it remains securely attached to the window.
- These WOCDs have been tested to meet the requirements of ASTM F2090-21.



WARNINGS:

- Failure to follow usage and maintenance instructions carefully may allow for accidental falls.
 - These WOCDs are not a substitute for attentive supervision of all young children.
 - Keep WOCDs engaged unless needed for exit in an emergency.
 - Windows with WOCDs installed will block escape in Fire or Emergency unless locked/recessed.
 - Maintain and check operation of WOCDs monthly. Replace the WOCDs if they do not operate correctly.
 - Instruct household members age six and older how to operate WOCDs in case of emergency.
 - WOCDs are designed to restrict the window opening to prevent accidental falls by children. When engaged, WOCDs must limit the sash operation so that a 4.0" (102mm) rigid sphere cannot pass through a clear opening.
 - Check the WOCD upon receipt to make sure the device is securely attached to the window.
 - Consult with local building and fire code departments before using WOCDs, for specific applicable codes.
 - WOCDs shall be installed such that the release mechanism(s) is in conformance with local building and fire code requirements.



WARNING: Possible Fall Hazard

- Young children may fall out of the window if the WOCDs are not installed correctly.
- Install the device so that a rigid 4.0" (102mm) diameter sphere does not pass through any space at the lowest opening portion in the window opening after the WOCDs are in place.
- Young children may fall out of the window if all instructions are not followed:
 - Use recommended materials and techniques.
 - Make sure that the WOCDs are securely attached in accordance with the manufacturer's instructions.
 - Make sure that the window frame is in good condition.